








- On the hole display, you have the most important information at a glance: the number of the hole, the prescribed number of strokes, the handicap, and the golf hole index are displayed in the top left corner.

The wind direction is displayed in the top left-hand corner

If the slope (+) / gradient (-) is more than 5%, the slope display appears on the right below the fairway display. In the center below you can read the distance to the center of the green.

The orange dot represents your current position on the fairway.

For better clarity, you can move the hole display with your fingers or enlarge/reduce it by rotating the crown.




By pressing the wind direction display, you will get to a view with more detailed information.

This includes the distance to the center of the green, the slope/downhill, and the wind speed.


You can return to the fairway display by clicking on the "<" icon in the top left corner.

At any time, you can display the distance from your current position to any point on the fairway. To do this, just click on a point within the display and the distance indicator at the bottom right turns red for 5 seconds and indicates the distance to that point. After 5 seconds, the distance indicator returns to its blue color and shows the distance to the center of the green again.



Tip: This function is very helpful for distances to obstacles (bunkers, water, out of bounds, etc.) and the flag position on the green.


- Swiping to the right brings you to the main menu. In the main menu, you can activate the "Simple Mode". This replaces the hole display with a simplified display, which only indicates the distance to the beginning, middle, and end of the green.




- With the "Workout" button, your watch switches to energy-saving mode. You can tell if it's activated by a yellow circle located to the left of the time.

If no circle is visible, please go to the settings for the Apple Watch and activate the energy-saving mode via the "Workout" menu item.

Afterwards, you can deactivate/activate the energy-saving mode at any time via the GolfWatch app.




- If you ever mistakenly start from the wrong track, for example, when all flights start simultaneously, you can return directly to the track selection from the main menu via "Back" and select the correct track.



- Through the "Score" section, you quickly get an overview of your current game result.

Here, you can find the total number of your shots, the gross and net result, as well as the number of your putts.

You will also see this screen after you have entered your scores for all 18 holes.




- From the scoreboard, you get to an overview by clicking on "Overview", where you can quickly and easily determine whether you've recorded your score for all the holes.


Holes marked in red have not had a score recorded yet. However, you can rectify this by selecting the missing course, recording the score, and saving it with a click on "Save".

By pressing "<" in the top left corner, you go back to the "Overview", and with another click on "<", you return to the main menu.

Swiping to the left takes you back to the course display.



11. After you have checked all the entries, you can end your round in the main menu with the "Finish Game" button. When you click on "Save & Finish", you will be asked for your email address and password, which you have registered on Golfwatch.de. Without this registration, you cannot submit your scorecard. With successful registration on Golfwatch.de, this only needs to be confirmed once in the app. After that, your watch is registered on Golfwatch.de. If your scorecard is incomplete, you will receive an additional notice here. You can then capture the missing entries using the "Overview" function.



On Golfwatch.de, you can now call up and analyze your saved round in the dashboard.

By confirming the "Finish" button, you leave the round without saving.

Now you are ready for the next round.